


Get started

1. Plug it into one of the USB ports of your computer.
If you are using a desktop PC, it will be better to plug it into the USB ports at the back of computer case instead of those in the front.
2. It is a plug & play webcam, so there is no extra driver needed. Please note that there is no icon or message for this webcam after it is successfully installed, but it do work.
3. To use it, you may need a third-party software like Skype.

More Information at
www.owlotech.com



USER MANUAL



OWLOTECH

WEBCAM **Essential**

With Built-in Microphone | USB Plug&Play